



- NOTES:
1. IF WIDER THAN 3', USE 3 SPRINGS PER HEMBAR.
 2. 8' MAX. LENGTH

SECTION

FRONT VIEW

CLEARSORBER™ FOIL (DUAL LAYER)
 U-PROFILE/SPRING/DUAL HEMBAR
 DIRECT MOUNT TO WINDOW MULLION

INSTALLATION

1. SECURE U-PROFILE TO TOP AND BOTTOM OF MULLION WITH SCREWS.
2. INSERT SPRINGS INTO HOLES IN TOP PROFILE.
3. HOOK HEMBARS TO TOP SPRINGS THROUGH PRE-DRILLED HOLES
4. PULL BOTTOM HEMBAR WITH SPRINGS/FOIL TAUGHT THEN HOOK FREE END OF SPRING INTO HOLES IN BOTTOM PROFILE.

NO SCALE

NOTE:
 WINDOW MULLIONS ARE SHOWN ILLUSTRATIVELY. ACTUAL MULLION DEPTH WILL VARY BASED ON APPLICATION.
 ALL HARDWARE PROVIDED UNLESS OTHERWISE NOTED.



99 SOUTH STREET, PASSAIC, NJ 07055
 (p) 973-916-1166 (e) estimating@rpgacoustic.com

Title: CLEARSORBER FOIL-DUAL DIRECT MOUNT OPT. 3

Proj: RPG PRODUCT

Date: 6/18/20 By: ZAH Scale: 1-1/2" = 1'-0"

Path: F:\Project Mgmt - RPG\PROJECTS\ALL PRODUCTS DRAWING\CLRF_Clearsorber Foil\AutoCAD Drawings\Mounting\Window Mounting - Direct Mount Options

Comments:
